

## Twin Combinations Size Chart

| Unit Dimension                       | 3'-7 1/2"<br>43 1/2" | 4'-3 1/2"<br>51 1/2" | 4'-11 1/2"<br>59 1/2" | 5'-7 1/2"<br>67 1/2" | 6'-3 1/2"<br>75 1/2" | 6'-11 1/2"<br>83 1/2" |
|--------------------------------------|----------------------|----------------------|-----------------------|----------------------|----------------------|-----------------------|
| Rough Opening                        | 3'-8"<br>44"         | 4'-4"<br>52"         | 5'-0"<br>60"          | 5'-8"<br>68"         | 6'-4"<br>76"         | 7'-0"<br>84"          |
| 3'-1"<br>37"<br>3'-1 1/2"<br>37 1/2" | 18210-2              | 20210-2              | 24210-2               | 28210-2              | 30210-2              | 34210-2               |
| 3'-5"<br>41"<br>3'-5 1/2"<br>41 1/2" | 1832-2               | 2032-2               | 2432-2                | 2832-2               | 3032-2               | 3432-2                |
| 4'-1"<br>49"<br>4'-1 1/2"<br>49 1/2" | 18310-2              | 20310-2              | 24310-2               | 28310-2              | 30310-2              | 34310-2               |
| 4'-5"<br>53"<br>4'-5 1/2"<br>53 1/2" | 1842-2               | 2042-2               | 2442-2                | 2842-2               | 3042-2               | 3442-2                |
| 4'-9"<br>57"<br>4'-9 1/2"<br>57 1/2" | 1846-2               | 2046-2               | 2446-2                | 2846-2               | 3046-2               | 3446-2                |
| 5'-5"<br>65"<br>5'-5 1/2"<br>65 1/2" | 1852-2               | 2052-2               | 2452-2                | 2852-2               | 3052-2               | 3452-2                |
| 5'-9"<br>69"<br>5'-9 1/2"<br>69 1/2" | 1856-2*              | 2056-2*              | 2456-2*               | 2856-2*              | 3056-2*              | 3456-2*               |
| 6'-5"<br>77"<br>6'-5 1/2"<br>77 1/2" | 1862-2               | 2062-2               | 2462-2                | 2862-2               | 3062-2               | 3462-2                |

• Window available in oriel style (Top sash smaller than bottom).

\* Our mulling system allows for easy to remember rough opening calculations. Just add the rough opening sizes for each single unit together. Example: 20210-2 = 2 x 2' 2" = net rough opening of 4' 4".